



INSTRUCTION MANUAL

DUAL BAND FM TRANSCEIVER

IC-2800H

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Icom Inc.


FOREWORD

READ ALL INSTRUCTIONS carefully and completely before using the transceiver.

SAVE THIS INSTRUCTION MANUAL — This instruction manual contains important operating instructions for the IC-2800H.

EXPLICIT DEFINITIONS


The explicit definitions below apply to this instruction manual.


WORD	DEFINITION
 WARNING	Personal injury, fire hazard or electric shock may occur.
CAUTION	Equipment damage may occur.
NOTE	If disregarded, inconvenience only. No risk of personal injury, fire or electric shock.




Versions of the IC-2800H which display the “CE” symbol on the serial number seal comply with the European harmonised standard ETS300 684 (EMC product standard for Commercially Available Amateur Radio Equipment).

CAUTIONS

 **WARNING! NEVER** connect the transceiver to an AC outlet. This may pose a fire hazard or result in an electric shock.

 **WARNING! NEVER** operate the transceiver while driving a vehicle. Safe driving requires your full attention—anything less may result in an accident.

 **WARNING! HIGH VOLTAGE! NEVER** disassemble the remote controller. There is a high voltage circuit inside.

NEVER connect the transceiver to a power source of more than 16 V DC or using reverse polarity. This will ruin the transceiver.

NEVER cut the DC power cable between the DC plug and fuse holder. If an incorrect connection is made after cutting, the transceiver may be damaged.

NEVER place the transceiver where normal operation of the vehicle may be hindered or where it could cause bodily injury.

NEVER let objects impede the operation of the cooling fan on the rear panel.

DO NOT push the PTT when not actually desiring to transmit.

DO NOT operate the transceiver near unshielded electrical blasting caps or in an explosive atmosphere.

During mobile operation, **DO NOT** operate the transceiver without running the vehicle's engine. When transceiver power is ON and your vehicle's engine is OFF, the vehicle's battery will soon become exhausted.

AVOID using or placing the transceiver in direct sunlight or in areas with temperatures below -10°C ($+14^{\circ}\text{F}$) or above $+60^{\circ}\text{C}$ ($+140^{\circ}\text{F}$).

AVOID the use of chemical agents such as benzine or alcohol when cleaning, as they can damage the transceiver's surfaces.

Place unit in a secure place to avoid inadvertent use by children.

BE CAREFUL! The transceiver will become hot when operating it continuously for long periods.

USE Icom microphones only (supplied or optional). Other manufacturer's microphones have different pin assignments and may damage the transceiver if attached.

For LCD display

DO NOT press the LCD screen. Excessive pressure may cause permanent damage to the LCD.

DO NOT tap or scratch the LCD using sharp objects.

BE CAREFUL when cleaning the LCD. Dust can easily scratch the surface.

LCDs are produced using high-density manufacturing technology resulting in 99.98% active dots, however, up to 0.02% of the dots may be non-active and/or continuously active. This is normal and does not indicate LCD malfunction.

Uneven areas may be displayed depending on display contents in some cases.

After displaying the same screen continuously for long periods, image 'burn-in' may occur. In such cases, turn the power OFF and discontinue operation for at least 24 hours.

For U.S.A. only

CAUTION: Changes or modifications to this device, not expressly approved by Icom Inc., could void your authority to operate this device under FCC regulations.


TABLE OF CONTENTS

1 SUPPLIED ACCESSORIES	1	■ Selecting output power	25	■ Transferring scratch pad memory contents	41	15 OTHER FUNCTIONS	63–75
2 PANEL DESCRIPTION	2–13	■ One-touch PTT function	25	9 SCAN OPERATION	42–46	■ Beep tones	63
■ Controller unit	2	6 REPEATER OPERATION ...	26–31	■ Scan types	42	■ Time-out timer	63
■ Function display	4	■ Accessing a repeater	26	■ Full/programmed scan	43	■ Auto power-off function	64
■ Basic function menu	6	■ 1750 Hz tone	28	■ Selecting scan edges	44	■ Cooling fan	64
■ Main unit	8	■ Subaudible tone	29	■ Memory scan	45	■ Squelch delay	65
■ HM-98 microphone	10	■ Offset frequency	30	■ Skip channel setting	46	■ Sub band mute	65
■ HM-97/118N microphone	13	■ Auto repeater function	31	■ Scan resume condition	46	■ Sub band busy beep	66
3 INSTALLATION	14–17	7 MEMORY/CALL CHANNELS	32–39	10 BAND SCOPE	47	■ Automatic RF attenuator	66
■ Location	14	■ General	32	■ Operation	47	■ Memory name indication	67
■ Mounting with the mounting bracket	14	■ Programming during selection	32	11 PRIORITY WATCH	48–49	■ HM-98 [F-1]/[F-2] keys	67
■ Mounting the remote controller	15	■ Programming after selection	33	■ Priority watch types	48	■ HM-97/118 [UP]/[DN] keys	68
■ Battery connection	15	■ Transferring memory contents to another memory	33	■ Priority watch operation	48	■ Display contrast	68
■ DC power supply connection	16	■ Programming during selection via the microphone	34	12 SUBAUDIBLE TONE OPERATION	50–53	■ Display brightness	69
■ Cable connection	16	■ Programming after selection via the microphone	34	■ Tone squelch operation	50	■ Indication type	69
■ Antenna installation	17	■ Transferring memory contents to another memory via the microphone	35	■ Pocket beep operation	52	■ My call function	69
4 FREQUENCY SETTING	18–22	■ Memory clear	36	■ Tone scan	53	■ Packet operation	70
■ Preparation	18	■ Alphanumeric display	37	13 DTMF MEMORY	54–56	■ Video monitor function	73
■ Lock functions	19	■ Call channel	38	■ Programming a DTMF code ..	54	■ Demonstration display	74
■ Using the tuning dial	20	8 SCRATCH PAD MEMORY ...	40–41	■ Transmitting a DTMF code ..	55	■ AM/FM narrow mode	74
■ Using the [▲]/[▼] keys	20	■ What is a scratch pad memory?	40	■ DTMF speed	56	■ Fuse replacement	74
■ Setting a tuning step	21	■ Calling up a scratch pad memory	40	14 WIRELESS OPERATION ...	57–62	■ Partial reset	75
■ Using the keypad	22			■ Connection	57	■ All reset	75
5 BASIC OPERATION	23–25			■ HM-90 wireless microphone ..	57	16 CS-2800 CLONING SOFTWARE	76–79
■ Receiving	23			■ EX-1759 installation	58	17 TROUBLESHOOTING	80
■ Monitor function	24			■ HM-90 switches	59	18 OPTIONS	81
■ Audio mute function	24			■ Microphone address	62	19 SPECIFICATIONS	82–83
■ Transmitting	24						

SUPPLIED ACCESSORIES

1

The transceiver comes with the following accessories.




Qty.

- ① DC power cable (OPC-346) 1
- ② Remote controller cable*1 1
- ③ Remote controller mounting bracket (MB-73) 1
- ④ Main unit mounting bracket 1
- ⑤ Mounting screws, nuts and washers 1 set
- ⑥ Fuse (FGB 20 A) 1
- ⑦ Remote controller mounting screws and nut 1 set
- ⑧ Microphone*2 (HM-98/97/118N) 1

*1 A ferrite core is attached at one end of the cable for the U.S.A., Europe and Taiwan versions.

*2 The microphones illustrated at left are the HM-98 and HM-118. One of either the HM-98, HM-97 or HM-118N/TN/TAN microphone is supplied depending on version.

■ Controller unit



❶ VHF VOLUME CONTROL [VOL]

Adjusts the VHF audio level. (p. 23)

❷ VHF SQUELCH CONTROL [SQL]

- ➡ Adjusts the VHF squelch level. (p. 23)
- ➡ Depending on the set mode setting, the RF attenuator is automatically activated when [SQL] is rotated clockwise past the 12 o'clock position. (pgs. 23, 66)

❸ VHF TUNING DIAL [DIAL]

Rotate [DIAL] to set operating frequencies, memory channels, set mode contents, etc. (p. 20)

❹ CHANGE/LOCK SWITCH [CHG/L]

- ➡ Toggles the multi-function switch menu. (p. 6)
- ➡ Push [CHG/L] for 2 sec. to toggle the lock function ON and OFF. (p. 19)

❺ POWER SWITCH [POWER]

Push for 2 sec. to toggle the transceiver power ON and OFF. (p. 18)

❻ UHF TUNING DIAL [DIAL]

Rotate [DIAL] to set operating frequencies, memory channels, set mode contents, etc. (p. 20)

❼ UHF SQUELCH CONTROL [SQL]

- ➡ Adjusts the UHF squelch level. (p. 23)
- ➡ Depending on the set mode setting, the RF attenuator is automatically activated when [SQL] is rotated clockwise past the 12 o'clock position. (pgs. 23, 66)

❽ VIDEO INPUT JACK [VIDEO IN]

Inputs an NTSC or PAL video signal depending on version. (p. 73)

❾ UHF VOLUME CONTROL [VOL]


Adjusts the UHF audio level. (p. 23)

❿ MULTI-FUNCTION SWITCHES (pgs. 6, 7)

- Push to select the function indicated in the right-hand or left-hand LCD display of these switches.
- Left-hand switches are used for VHF band and right-hand switches are used for UHF band.
- Functions vary depending on the operating condition.

2 PANEL DESCRIPTION

■ Function display



1 FUNCTION INDICATORS (pgs. 6, 7)

Indicate the functions assigned to the multi-function switches at left.

2 DTMF MEMORY ENCODER INDICATOR (p. 54)

Appears when the DTMF memory encoder is in use.

3 LOCK INDICATOR (p. 19)

Appears when the lock function is in use.

4 TIME-OUT TIMER INDICATOR (p. 63)

- Appears when the time-out timer is activated.
- Flashes when the time-out time elapses and the transmission is terminated.

5 S/R/F INDICATOR

Shows the relative signal strength while receiving. Shows the relative output power while transmitting. (pgs. 23, 24)

- "RX" appears when receiving a signal or when the squelch is open.
- "TX" appears when transmitting.

6 FUNCTION INDICATORS (pgs. 6, 7)

Indicate the functions assigned to the multi-function switches at right.

7 AUTO POWER-OFF INDICATOR (p. 64)

Appears when the auto power-off function is in use.

8 MEMORY CHANNEL READOUT

Shows the memory or call channel number, etc.

- "M" appears when a memory channel is selected. (p. 18)
- "P" appears when a selected memory channel is set as a skip channel. (p. 46)
- "P" appears when the memory channel frequency is set as a skip frequency during scanning. (p. 46)

Count on us!

A-5570H-1EX-③
Printed in Japan
© 1999 Icom Inc.

Icom Inc.
1-1-32 Kamiminami, Hirano-ku, Osaka 547-0003 Japan