

ATIS code PROGRAMMING INFORMATION for IC-M411

The 10-digit ATIS code can be programmed and confirmed with the following operation.

◇ Programming procedure

- ① While pushing **[MENU]**, turn power ON.
 - Turn power OFF in advance.
- ② After the display appears, release **[MENU]**.
- ③ Push **[MENU]** to enter the DSC menu.
- ④ Push **[▲]** or **[▼]** to select “ATIS” and push **[ENT]**.
 - A cursor starts blinking.



- ⑤ Input the specified ATIS code by pushing **[▲]** or **[▼]**.
 - Push **[CH•DUAL]** or **[16•C]** to move the cursor forward or backward, respectively.
- ⑥ After inputting the 10-digit ATIS code, push **[ENT]**.
 - “CONFIRMATION” scrolls at the channel comment indicator.



- ⑦ Push **[ENT]**, then input the same ATIS code as step ⑤ for the confirmation.

/// The ATIS code programming is not necessary and confirmation can only be performed when the ATIS code has been programmed by your dealer. The code programming can be performed 1 time only, when the code has not been programmed by your dealer.

- ⑧ Push **[ENT]** to set the code.
 - Returns to the normal operation.
 - Push **[CLR]** to cancel and exit the condition.
 - If the different code is input, “INCORRECT” appears. Push **[ENT]** and try steps ⑤ to ⑦ again.

◇ ATIS code confirmation

(When the ATIS code has been programmed)

- ① Push **[MENU]** to enter the DSC menu.
- ② Push **[▲]** or **[▼]** to select “ATIS” and push **[ENT]**.
 - The ATIS code is displayed and scrolls at the channel comment indicator.
 - When no ATIS code is programmed, “NO ID” appears.



- ③ Push **[ENT]** to return to the normal operation.