

INSTRUCTION MANUAL

VHF MARINE TRANSCEIVER

IC-M504A



Icom Inc.

FOREWORD

Thank you for purchasing this Icom product. The IC-M504A VHF MARINE TRANSCEIVER is designed and built with Icom's state of the art technology and craftsmanship. With proper care, this product should provide you with years of trouble-free operation.

We appreciate you making the IC-M504A your radio of choice, and hope you agree with Icom's philosophy of "technology first." Many hours of research and development went into the design of your IC-M504A.

♦ FEATURES

- O Simple operation with large keys
- O Easy to hear speaker
- O Built-in DSC meets ITU Class D requirement
- O Rugged waterproof construction
- Optional COMMANDMICII™ (HM-157) and COMMANDMICIII™ (HM-162) are available
- O Easy to make individual DSC calls using Icom's MA-500TR Class B AIS Transponder

IMPORTANT

READ ALL INSTRUCTIONS carefully and completely before using the transceiver.

SAVE THIS INSTRUCTION MANUAL — This instruction manual contains important operating instructions for the IC-M504A.

EXPLICIT DEFINITIONS

WORD	DEFINITION
∆WARNING!	Personal injury, fire hazard or electric shock may occur.
CAUTION	Equipment damage may occur.
NOTE	If disregarded, inconvenience only. No risk of personal injury, fire or electric shock.

CLEAN THE TRANSCEIVER AND MICROPHONE THOROUGHLY WITH FRESH WATER after exposure to water including salt, otherwise, the keys and switch may become inoperable due to salt crystallization.

IN CASE OF EMERGENCY

If your vessel requires assistance, contact other vessels and the Coast Guard by sending a Distress call on Channel 16.

USING CHANNEL 16 DISTRESS CALL PROCEDURE

- 1. "MAYDAY MAYDAY MAYDAY."
- 2. "THIS IS" (name of vessel).
- Say your call sign or other description of the vessel (AND 9 digit DSC ID if you have one).
- 4. "LOCATED AT" (your position).
- 5. State the nature of the distress and assistance required.
- Give any other information which might facilitate the rescue.

Or, transmit your Distress call using digital selective calling on Channel 70.

USING DIGITAL SELECTIVE CALLING (Ch 70) DISTRESS CALL PROCEDURE

- While lifting up the key cover, hold down [DISTRESS] for 5 seconds until you hear 5 short beeps and then one long beep.
- 2. Wait for an acknowledgment on Channel 70 from a coast station.
 - After the acknowledgement is received, Channel 16 is automatically selected.
- 3. Hold down [PTT], then transmit the appropriate information as listed above.

NOTE

A WARNING STICKER is supplied with the transceiver. To comply with FCC regulations, this sticker must be affixed in such a location as to be readily seen from the operating controls of the radio as in the diagram below. Make sure the chosen location is clean and dry before applying the sticker.

EXAMPLE



RADIO OPERATOR WARNING



Icom requires the radio operator to meet the FCC Requirements for Radio Frequency Exposure. An omnidirectional antenna with gain not greater than 9 dBi must be mounted a minimum of 5 meters (measured from the lowest point of the antenna) vertically above the main

deck and all possible personnel. This is the minimum safe separation distance estimated to meet all RF exposure compliance requirements. This 5 meter distance is based on the FCC Safe Maximum Permissible Exposure (MPE) distance of 3 meters added to the height of an adult (2 meters) and is appropriate for all vessels.

For watercraft without suitable structures, the antenna must be mounted so as to maintain a minimum of 1 meter vertically between the antenna, (measured from the lowest point of the antenna), to the heads of all persons AND all persons must stay outside of the 3 meter MPE radius.

Do not transmit with radio and antenna when persons are within the MPE radius of the antenna, unless such persons (such as driver or radio operator) are shielded from antenna field by a grounded metallic barrier. The MPE Radius is the minimum distance from the antenna axis that person should maintain in order to avoid RF exposure higher than the allowable MPE level set by FCC.

FAILURE TO OBSERVE THESE LIMITS MAY ALLOW THOSE WITHIN THE MPE RADIUS TO EXPERIENCE RF RADIATION ABSORPTION WHICH EXCEEDS THE FCC MAXIMUM PERMISSIBLE EXPOSURE (MPE) LIMIT. IT IS THE RESPONSIBILITY OF THE RADIO OPERATOR TO ENSURE THAT THE MAXIMUM PERMISSIBLE EXPOSURE LIMITS ARE OBSERVED AT ALL TIMES DURING RADIO TRANSMISSION. THE RADIO OPERATOR IS TO ENSURE THAT NO BYSTANDERS COME WITHIN THE RADIUS OF THE MAXIMUM PERMISSIBLE EXPOSURE LIMITS.

Determining MPE Radius

THE MAXIMUM PERMISSIBLE EXPOSURE (MPE) RADIUS HAS BEEN ESTIMATED TO BE A RADIUS OF ABOUT 3M PER OET BULLETIN 65 OF THE FCC. THIS ESTIMATE IS MADE ASSUMING THE MAXIMUM POWER OF THE RADIO AND ANTENNAS WITH A MAXIMUM GAIN OF 9dBi ARE USED FOR A SHIP MOUNTED SYSTEM.

TABLE OF CONTENTS

FC	DREWORD	
IM	IPORTANT	
ΕX	(PLICIT DEFINITIONS	
IN	CASE OF EMERGENCY	i
NC	OTE	i
	ADIO OPERATOR WARNING	
	ABLE OF CONTENTS	
PF	RECAUTIONS	
1	OPERATING RULES	·
2	PANEL DESCRIPTION	2–5
	■ Front panel	2
	■ Function display	
	■ Speaker Microphone	
3	BASIC OPERATION	6–1 ⁻
	■ Channel selection	
	■ Receiving and transmitting	8
	■ Call channel programming	
	Channel comments	
	Microphone Lock function	
	Display backlight	10
	Optional voice scrambler operation	
4	SCAN OPERATION	
	Scan types	12
	■ Setting TAG channels Starting a scan	
_	DUALWATCH/TRI-WATCH	
5	■ Description	
	■ Operation	
6	DSC OPERATION	
0	■ MMSI code programming	15–47
	■ DSC address ID	
	■ Position and time programming	
	T conton and time programming	

	■ Position and time indication		1
	■ GPS information display		1
	■ Distress call		2
	■ Transmitting DSC calls		2
	■ Receiving DSC calls	;	3
	■ Received messages		
	■ DSC Set up menu		
7	OTHER FUNCTIONS	48 <u>–</u>	5
	■ Intercom operation		
	RX Speaker function		
	■ Hailer operation		
	■ Automatic Foghorn function		
8	SET MODE		
-	■ Set mode programming		
	■ Set mode items.		
9	CONNECTIONS AND MAINTENANCE	56-	6
	■ Connections		
	■ Antenna		
	■ Fuse replacement		
	■ Cleaning		5
	■ Supplied accessories		5
	■ Mounting the transceiver		
	■ MB-75 installation		6
	■ UT-112/UT-98 installation		
	■ Microphone installation		6
10	TROUBLESHOOTING		
11	SPECIFICATIONS AND OPTIONS	68-	6
	■ Specifications		
	■ Options		
12	CHANNEL LIST		7
	TEMPLATE		
	FCC INFORMATION		
14			1

ช

PRECAUTIONS

⚠ WARNING! NEVER connect the transceiver to an AC outlet. This may pose a fire hazard or result in an electric shock.

⚠ WARNING! NEVER connect the transceiver to a power source of more than 16 V DC or use reverse polarity. This will ruin the transceiver.

⚠ WARNING! NEVER cut the DC power cable between the DC plug at the back of the transceiver and fuse holder. If an incorrect connection is made after cutting, the transceiver may be damaged.

CAUTION: NEVER place the transceiver where normal operation of the vessel may be hindered or where it could cause bodily injury.

CAUTION: Changes or modifications to this device, not expressly approved by Icom Inc., could void your authority to operate this device under FCC regulations.

KEEP the transceiver and microphone at least 1 m (3.3 ft) away from the vessel's magnetic navigation compass.

DO NOT use or place the transceiver in areas with temperatures below –20°C (–4°F) or above +60°C (+140°F) or, in areas subject to direct sunlight, such as the dashboard.

DO NOT use harsh solvents such as benzine or alcohol to clean the transceiver, as they will damage the transceiver's surfaces. If the transceiver becomes dusty or dirty, wipe it clean with a soft, dry cloth.

BE CAREFUL! The transceiver rear panel will become hot when operating continuously for long periods of time.

Place the transceiver in a secure place to avoid inadvertent use by children.

BE CAREFUL! The transceiver and the optional HM-157 COMMANDMICII™/HM-162 COMMANDMICIII™ meet IPX8 requirements for waterproof protection. However, once the transceiver has been dropped, waterproof protection cannot be guaranteed because of possible damage to the transceiver's case or the waterproof seal.

Icom, Icom Inc. and the Icom Iogo are registered trademarks of Icom Incorporated (Japan) in Japan, the United States, the United Kingdom, Germany, France, Spain, Russia and/or other countries.

COMMANDMIC is a registered trademark of Icom Incorporated (Japan) in Japan and the United States.

OPERATING RULES

♦ Priorities

- Read all rules and regulations pertaining to call priorities, and keep an up-to-date copy handy. Safety and distress calls take priority over all others.
- You must monitor Channel 16 when you are not operating on another channel.
- False or fraudulent distress calls are prohibited under law.

♦ Privacy

- Information overheard, but not intended for you, cannot lawfully be used in any way.
- Indecent or profane language is prohibited.

♦ Radio licenses

(1) SHIP STATION LICENSE

You may require a current radio station license before using the transceiver. It is unlawful to operate a ship station which is not licensed, but required to be.

If required, contact your dealer or the appropriate government agency for a Ship-Radiotelephone license application. This government-issued license states the call sign which is your craft's identification for radio purposes.

(2) OPERATOR'S LICENSE

A Restricted Radiotelephone Operator Permit is the license most often held by small vessel radio operators when a radio is not required for safety purposes.

If required, the Restricted Radiotelephone Operator Permit must be posted or kept with the operator. If required, only a licensed radio operator may operate a transceiver.

However, non-licensed individuals may talk over a transceiver if a licensed operator starts, supervises, ends the call and makes the necessary log entries.


A current copy of the applicable government rules and regulations is only required to be on hand for vessels in which a radio telephone is compulsory. However, even if you are not required to have these on hand it is your responsibility to be thoroughly acquainted with all pertinent rules and regulations.

NOTE: Even though the IC-M504A is capable of operation on VHF marine channels 3, 21, 23, 61, 64, 81, 82 and 83, according to FCC regulations these simplex channels cannot be lawfully used by the general population in USA waters.

2

PANEL DESCRIPTION

■ Front panel



The microphone may be connected here, or the microphone and its connection kit for the rear panel are separately included, depending on the transceiver version.

See pages 58 and 62 for details.

- ◆ DISTRESS KEY [DISTRESS] (pp. 20, 22) Hold down for 5 seconds to transmit a Distress call.
- **2 DSC MENU KEY [MENU]**Push to toggle the DSC menu appear or disappear. (p. 15)
- **3 CLEAR KEY [CLR]** (pp. 9, 55) Push to cancel the entered function, exit Set mode.

4 HAIL/RX SPEAKER KEY [HAIL•RX 🐠]

- → Push to turn the hailer mode ON or OFF. (p. 50)
- → Hold down for 1 second to turn the RX Speaker mode ON or OFF. (p. 49)
- → While holding down [H/L], push to turn the Automatic Foghorn function ON. (p. 51)

⑤ ATTENUATOR/INTERCOM KEY [LO/DX•IC•SCRM]

- ➡ Push to turn the Attenuator function ON or OFF. (p. 8)
 "LOC" appears when the Attenuator function is turned ON.
- → Hold down for 1 second to activate an optional Intercom function. (p. 48)
- → Hold down to call the optional Command microphone while in Intercom mode. (p. 48)
- ➡ While holding down [H/L], push to turn the Voice Scrambler function ON or OFF. (p. 11)

6 CHANNEL 16/CALL CHANNEL KEY [16•9]

- ⇒ Push to select Channel 16. (p. 6)
- ➡ Hold down for 1 second to select Call channel. (p. 6)
 "CALL" appears when Call channel is selected.
- → Hold down for 3 seconds to enter Call channel programming mode when Call channel is selected. (p. 9)
- → While holding down [H/L], push to enter the channel comment programming mode. (p. 9)
- ⇒ Push to move the cursor forward while in the channel comment programming mode. (p. 9)
- ➤ While turning power ON, push to enter Set mode. (p. 53)

7 CHANNEL SELECTOR [DIAL•ENTER]

- ⇒ Rotate to select the operating channels, Set mode settings, etc. (pp. 6–8, 53)
- ➡ While holding down [H/L], rotate to adjust the brightness of the LCD and key backlight. (p. 10)
- → Push to enter the input channel comment, selected item, etc. (pp. 9, 53)
- ➡ Rotate to check TAG channels, changes scanning direction or resumes the scan manually during scan. (p. 13)
- → While holding down [HAIL•RX 🐠], rotate to adjust the audio level in RX Speaker mode. (p. 49)
- → Hold down for 1 second to display the GPS information when a GPS receiver is connected. (p. 19)

③ CHANNEL/WEATHER CHANNEL KEY [CH/WX•DUAL•U/I/C]

- Selects and toggles the regular channel and Weather channel when pushed momentarily. (p. 7)
- → Hold down for 1 second to start Dualwatch or Tri-watch. (p. 14)
- → Push to stop Dualwatch or Tri-watch when either is activated. (p. 14)
- ⇒ Push to move the cursor backward while in the channel comment programming mode. (p. 9)
- While holding down [H/L], push to select one of three channel groups in sequence. (p. 7)
 - U.S.A., International and Canadian channels are available.

SQUELCH CONTROL [SQL]

Rotate to set the squelch threshold level. (p. 8)

® SCAN/TAG KEY [SCAN•TAG] (p. 13)

- Push to start and stop Normal or Priority scan.
- → Hold down for 1 second to set or clear the displayed channel as a TAG (scanned) channel.
- → While holding down [H/L], hold down for 3 seconds to clear or set all TAG channels in the selected channel group.

1 VOLUME CONTROL [VOL] (p. 8)


Rotate to adjust the audio level.

TRANSMIT POWER KEY [H/L]

- ⇒ Push to toggle the power high or low. (p. 8)
 - Some channels are set to low power only.
- While pushing this key, some keys perform secondary functions.

(B) POWER KEY [POWER] (p. 8)

- ⇒ Push to turn power ON.
- → Hold down for 1 second to turn power OFF.



A-6932D-1US Printed in Japan © 2011 Icom Inc.

Printed on recycled paper with soy ink.

Icom Inc.

1-1-32 Kamiminami, Hirano-ku, Osaka 547-0003, Japan